

The E-A-R® Classic® is the most trusted hearing protector in the world

E-A-R The RIGHT fit

The best plug recovery For Consistent fit

- Testing shows that after rolling down, an earplug should take 15 to 25 seconds to recover to 90% of its original size. Faster recoveries don't give users a chance to get the plug into their ears, slower recoveries cause users to hold the plug in their ear while waiting for recovery.
- Users know that the Classic will be firm enough to insert but secure and comfortable when it recovers. Other PVC plugs are flimsy when inserting, leading to poor fit and frustrated wearers.

E-A-R The RIGHT size

The Classic earplug size has been proven by 30 years of successful hearing conservation

- The E-A-R Classic earplug diameter is 0.54 inches. After reviewing anthropometric data and foam characteristics, this size was selected to provide an effective seal in the greatest number of ear canals. Smaller earplug diameters will not seal as many larger ear canals and larger diameters may be unable to fit small ear canals.
- The E-A-R Classic earplug length is 0.72 inches. This length ensures a secure, comfortable seal and high performance. Longer plugs may become uncomfortable even when properly inserted

E-A-R The RIGHT package

The Classic comes in an assortment of packages

- Classic packages include polybag, paper, bulk dispenser, 5-pair, Econopacks, and our trademark Pillow Pack® - pick the right package that works for you.



E-A-R The RIGHT price

The E-A-R Classic is available in a wide range of pricing options

- From large ECONOPACKS to Value Paks to Classic with cord for convenient storage.

**The RIGHT earplug for your hearing protection needs.
Don't settle for anything less!**



To order, call your local E-A-R distributor



The RIGHT choice